PLCD15V

15-INCH TFT-LCD MONITOR



INSTRUCTION MANUAL

Please read this manual thoroughly before use, and keep it handy for future reference.

CONTENTS


SAFETY INSTRUCTION	2 - 3
CAUTIONS	4
FCC RF INTERFERENCE STATEMENT	5
CONNECTING WITH EXTERNAL EQUIPMENT	6
REMOTE FUNCTIONS	7
CONTROLS AND FUNCTIONS	8 - 14
MOUNTING GUIDE	15
D-SUB CONNECTOR PIN ASSIGNMENTS	16
POWER MANAGEMENT	17
SPECIFICATIONS	18
TROUBLESHOOTING GUIDE	19

This Monitor was Manufactured by ISO 9001 Certified Factory

SAFETY INSTRUCTION

Important Safety Instruction

- 1. Read these instructions.
- 2. Keep these Instructions.
- 3. Heed all warnings.
- 4. Follow all instructions.
- 5. Do not use this apparatus near water.
- 6. Clean only with dry cloth.
- 7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions..
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug.
 - Apolarized plug has two blades with one wider than the other.
 - Agrounding type plug has two blades and a third grounding prong.
 - The wide blade or the third prong are provided for your safety.
 - If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
- 11. Only use attachment/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the apparatus. When a cart is used,
 - use caution when moving ..
 - the cart/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.




such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus the apparatus has been exposed to rain or moisture does not operate normally or has been dropped.

SAFETY INSTRUCTION

"WARNING - To reduce the risk of fire or electric shock, do not expose the apparatus to rain or moisture."

"The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus."





This symbol is intended to alert the user to the presence of uninsulated : dangerous voltage" with in the product's enclosure that may be of sufficient magnitude to constitute arisk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance(servicing) instructions in the literature accompanying the appliance.

CAUTIONS

CAUTION

The power supply cord is used as the main disconnect device, ensure that the socket-outlet is located/installed near the equipment and is easily accessible.

ATTENTION

Le cordon d'alimentation est utillsé comme interrupteur général. La prise de courant doit être située ou installée à proximité du matériel et être facile d'accès

CAUTION TO SERVICE PERSONNEL

POWER SUPPLY CORD IS USED AS MAIN POWER DISCONNECT DEVICE IN THIS PRODUCT, UNPLUG THIS PRODUCT FROM THE WALL OUTLET BEFORE REMOVING THE BACK COVER AND SERVICING

EMISSION CHARACTERISTICS TESTED BY SEMKO

THIS PRODUCT HAS BEEN TESTED AND HAS SHOWN COMPLIANCE WITH THE NATIONAL SPECIFICATIONS SUCH AS SWEDISH MPR 1990.10.(MPR II)

► NEVER REMOVE THE BACK COVER

Removal of the back cover should be carried out only by qualified personnel.

▶ DO NOT USE IN HOSTILE ENVIRONMENTS

To prevent shock or fire hazard, do not expose the unit to rain or moisture.

This unit is designed to be used in the office or home. Do not subject the unit to vibrations, dust of corrosive gases.

▶ KEEP IN A WELL VENTILATED PLACE

Ventilation holes are provided on the cabinet to prevent the temperature from rising. Do not cover the unit or place anything on the top of unit.

► AVOID HEAT

Avoid placing the unit in direct sunshine or near a heating appliance.

► TO ELIMINATE EYE FATIGUE

Do not use the unit against a bright back ground and where sunlight or other light sources will shine directly on the monitor.

▶ BE CAREFUL OF HEAVY OBJECT

Neither the monitor itself nor any other heavy object should rest on the power cord. Damage to a power cord can cause fire or electrical shock.

INSTRUCTION MANUAL	

FCC RF INTERFERENCE STATEMENT

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio, TV technician for help.
- Only shielded interface cable should be used.

Finally, any changes or modifications to the equipment by the user not expressly approved by the grantee or manufacturer could void the users authority to operate such equipment.


▶ DOC COMPLIANCE NOTICE

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the radio interference regulation of Canadian Department of communications.

INSTRUCTION I	ΜΔΝΙΙΔΙ

CONNECTING WITH EXTERNAL EQUIPMENT

A. BOTTOM PANEL CONTROL



- 1. DC 12V IN
- 2. D-SUB IN

PC Signal Input

3. VIDEO 1(AV1) IN

Composite signal Input for AV1

4. VIDEO 1(AV1) OUT

Video looping output for AV1

5. VIDEO 2(AV2) IN

Composite signal Input for AV2

6. VIDEO 2(AV2) OUT

Video looping output for AV2

7. AUDIO L IN

Stereo Audio L Signal Input, This input is for AV1, AV2, S-VIDEO

8. AUDIO R IN

Stereo Audio R Signal Input, This input is for AV1, AV2, S-VIDEO

9. S-VIDEO (Y/C) IN

Y/C separated signal input

10. S-VIDEO (Y/C) OUT

Y/C separated signal looping output

11. PC STEREO IN

REMOTE FUNCTIONS

B. REMOTE CONTROLLER

1. POWER((b))

Turns the power ON or OFF. There will be a few seconds delay before the display appears.

2. SOURCE

Select pc or video(PC / AV1 / AV2 / S-Video) sources.

3. MUTE

Mute the sound.

4. MENU

Activates and exits the On Screen Display.

5. VOL(**▼**▶)

Increases or decreases the level of audio volume.

6. UP/DOWN(▲▼)


Move to OSD menu.


7. AUTO

Auto geometry adjustment in PC Source.

8. EXIT

Exit the On Screen Display.





1. SOURCE

Select input source, and move the previous menu.

2. MENU

Activates and exits the On Screen Display.

This button can also be used to move previous menu or status.

OSD MENU(MAIN): Input Source, Screen, Audio, OSD, Color, Utility, Exit.

3/4. DOWN / UP

This button allows user to enter the sub-menu of the activated function when down key is pressed on the main menu.

5/6. **▼** VOL ▶

Adjust the volume / Adjust menu settings.

7. IR Sensor

Remote controller sensor.

8. POWER ON/OFF(\circlearrowleft)

Turns the power ON or OFF. There will be a few seconds delay before the display appears.

The power LED(next to the power switch) lights with green when the power is turned ON.

The power is turned off by pressing the power switch again and the power LED goes Red.

1. SELF-TEST DISPLAY


When there is no connection at PC, the On Screen Display will show for 3 seconds.





2. OSD MENU DESCRIPTION



Select PC or AV1, SVIDEO.







: Brightness

Increase or decrease the intensity of the image.

👺 : Contrast

Increase or decrease the intensity (lightness or dimness) of the image.

: H. position (PC Mode Only)

Move image horizontally on screen right or left.

: V. position (PC Mode Only)

Move image vertically on screen up or down.


: Clock (PC Mode Only)

Adjust the vertical noise of screen image.

: Phase (PC Mode Only)

Adjust the number of horizontal picture elements.


= : Audio



್ು: Volume

Adjust audio volume.

OSD: OSD



: H. Position

Move the OSD position to right(►) or left(◄).



: V. Position

Move the OSD position to up(►) or down(◄).

: Transparency

Select the OSD background.


① : OSD Timer

Select the OSD display timing.

A: Language

Select a language among English, Français, Deutsch, Español, Danish, Italiano.





[®]K : Color Temp

Adjust color temperature to 9300, 6500, user.

(note: 9300 is factory default)

Red:

Adjust red color for user.


: Green

Adjust green color for user.

: Blue

Adjust blue color for user.

☆: Utility




C: Recall

Select to reset all setting to the factory default values.



Select ON or OFF (ON: Control key lock. OFF: Control key unlock)









Turn off OSD Menu.

MOUNTING GUIDE

Wall mountable using two methods:

- 1) Using the 200 mm pre-cut holes
- 2) Using the VESA standard wall mount design and the 100mm hole pattern on the back panel to install the LCD monitor to the wall.






D-SUB CONNECTOR PIN ASSIGNMENTS

► PIN ASSIGNMENTS

Pin 1	RED VIDEO	9	
2	GREEN VIDEO	10	SIGNAL CABLE DETECT
3	BLUE VIDEO	11	GROUND
4	GROUND	12	SDA(for DDC)
5	GROUND	13	H-SYNC.(or H+V SYNC.)
6	RED GROUND	14	V-SYNC.
7	GREEN GROUND	15	SCL(for DDC)
8	BLUE GROUND		

D-SUB



► ACCESSORY

- 1. POWER CORD
- 2. USER'S MANUAL
- 3. PC cable
- 4. Adaptor
- 5. Remote Control
- 6. Batteries
- 7. Wall mount (Option)
- 8. Rack mount (Option).

POWER MANAGEMENT

This monitor features a power management system to "power down" upon receipt of the VESA DPMS(The display power management signaling) from a VESA DPMS video card.

The VESA DPMS-compliant video card performs this signaling system through not sending horizontal, vertical, or sync signal.

This monitor enters an appropriate mode through identifying each of the three modes of the signaling system.

POWER CONSUMPTION

MODE	POWER CONSUMPTION
ON	< 36W
STANDBY	< 5W
SUSPEND	< 5W
ACTIV OFF	< 5W

LED INDICATOR

The power management feature of the monitor is comprised of four stages : On(Green), Standby, Suspend, Active off(Amber) and Unsupported mode(Green).

MODE	LED COLOR	MONITOR OPERATION
ON	GREEN	Normal Operation
STANDBY		Screen blanks after preset idle time
SUSPEND	AMBER	and some electronic circuits or all
ACTIVE OFF		circuitry in the monitor shut down.
UNSUPPORTED MODE	GREEN	Normal operation but the on screen display will show error massage.
POWER OFF	RED	Not opreation

SPECIFICATIONS

► LCD Type

15" Diagonal AM-TFT(Active-Matrix)
Pixel pitch (mm): 0.297(H) 0.297(V)

BRIGHTNESS: 250cd/m²(Typical)
CONTRAST RATIO:600:1(Typical)
RESPONSE TIME: 8msec (Typical)

► RESOLUTION(H x V)

1024X768 @ 60Hz

► FREQUENCY

HORIZONTAL: 31KHz - 48KHz

VERTICAL: 56Hz - 75Hz

▶ INPUT SIGNAL

RGB (Analog 0.7Vp-p / 75Ω)

SYNC(Separate TTL Level)

AV(2ch input 1.0Vp-p, 75Ω terminated, loop-through out)

S-VIDEO(1ch input (Y/C), loop-through out),

AV(composite, S-VIDEO) Sound L/R

PC Stereo Sound

► ACTIVE DISPLAY AREA (W x H)

304.1mm X 228.1mm

► PACKING DIMENSIONS (W x D x H)

435mm X472mm X 233mm

▶ WEIGHT

Net Weight : 3.7Kg Gross Weight : 5.7Kg

► ELECTRICAL RATINGS

DC 12V/3A

► NOTE:

Technical specifications are subject to change without notice.

TROUBLESHOOTING GUIDE

TROUBLE	TROUBLESHOOTING TIP
No image on display screen	Check that power cord of the Monitor have been connected securely into wall outlet or grounded extension cable or strip. Power switch should be in the ON position
	and LED is lit.
	 Check that the Brightness and/or the Contrast adjustments of the Display have not been turned down to minimum levels.
"Going to Sleep" message on screen	The signal cable should be completely connected to the video card/computer.
	The video card should be completely seated in its slot and the computer is switched ON.
Display image is not centered, too small or too large in PC mode	Push the down key in front side or Auto key in remo∞n.
Vertical or Horizontal noise is present in the picture	Adjust Clock and Phase in the OSD.

WEEE Symbols

Correct Disposal of This Product (Waste Electrical &Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking shown on the product or its literature,indicates that it should not be disposed with

other household wastes at the end of its working life.To prevent possible harm to the

environment or human health from uncontrolled waste disposal, please separate this from other

types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product,or their

local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase

contract. This product should not be mixed with other commercial wastes for disposal.

